


Techbelt PTFE Welding Machine

Safety and Operating Manual


WARNING

IMPROPER OR UNSAFE use of this splice press can result in damage to the press and/or physical harm. This manual contains important information about product function and safety. Please read and understand this manual BEFORE operating the press. Please keep this manual available for other users and owners before they use the press.



SPECIFICATION	
Model	PI-75
Max temperature	380°C
Heating area size	75*30mm
Voltage	240V &110v

Description



1.

Power Plug:

Plug it in and the iron will begin to heat up.




Please DO NOT touch the heating iron during heating!

2. It takes 20 minutes to heat to 380°C

*The heating element has a max power for 380°C, it will not heat up further.

3. Repair the materials after heating.

4. Finished work, put the iron tool on the stand to cool.



SPARE PARTS - Heating Tube

